

## Solid State Broadband High Power Amplifier

**1191 – BBM5K8CKT**
**2500 – 6000 MHz / 100 Watts**

The BBM5K8CKT (SKU 1191) is a 2500 to 6000 MHz amplifier which is guaranteed to deliver 100W minimum output power and related RF performance under all specified temperature and environmental conditions. Typical power output is 125W and other typical performance parameters are also listed as a guide for consideration, but not guaranteed. This amplifier is suitable for broadband mobile jamming and band specific high power linear applications in the S and C frequency bands. This compact module utilizes the latest high power RF GaN transistors and also features built in control and monitoring, with protection functions to ensure high availability.



- Solid-state Class AB linear design
- Instantaneous ultra broadband
- Suitable for CW, AM, and FM (Consult factory for other modulation types)
- Small and lightweight
- 50 ohm input/output impedance
- High reliability and ruggedness
- Built-in control, monitoring and protection circuits
- RS485 serial interface for monitoring and control

### ELECTRICAL SPECIFICATIONS @ 28.0V<sub>DC</sub>, Over Temperature and Environmental Conditions, as specified.

Parameter	Symbol	Units	Test Conditions	Min	Typ	Max
Operating frequency	BW	MHz		2500		6000
Peak output power	P <sub>SAT</sub>	W	CW input signal	100	125	
Gain, small signal	G <sub>SS</sub>	dB	Measured with VNA in swept frequency mode at -20dBm CW. Input power calibrated / measured at the amplifier input port. Variable attenuator set to nominal attenuation.	55	60	65
Gain flatness small signal	ΔG <sub>SS</sub>	dB	Test conditions the same as G <sub>SS</sub>			±5
Gain adjustment range	G <sub>ADJ</sub>	dB	Test conditions the same as G <sub>SS</sub>	15		
Gain adjustment step size	G <sub>STEP</sub>	dB	Test conditions the same as G <sub>SS</sub>	0.5		
Maximum input power without damage	P <sub>IN, Max</sub>	dBm	CW input signal for unlimited duration.			20
Input return loss	IRL	dB	Measured with VNA in swept frequency mode at -20dBm and 0dBm CW. Input power calibrated / measured at the amplifier input port. Variable attenuator set to nominal attenuation.			-10
Noise figure	NF	dB	Variable attenuator set to nominal attenuation.			20
2 <sup>nd</sup> harmonics	2 <sup>nd</sup>	dBc	Variable attenuator set to nominal attenuation. CW signal source at an output power of 100W.			-10
3 <sup>rd</sup> harmonics	3 <sup>rd</sup>	dBc	Variable attenuator set to nominal attenuation. CW signal source at an output power of 100W.			-20
Spurious	Spur	dBc	Variable attenuator set to nominal attenuation. CW signal source of 0dBm at the input to the amplifier. Input power is calibrated / measured at the amplifier input port. Spurious defined as any non-harmonic amplifier output. Spurious measured in a 1kHz resolution bandwidth, 10kHz video bandwidth. Specifications apply at offsets of greater than or equal to +/- 10kHz from the RF carrier. Maximum measurement frequency is 6.5GHz.			-60
Operating voltage	V <sub>DC</sub>	V	Note: Output power capabilities and gain will vary with voltage.	26	28	32
Current consumption	I <sub>DC</sub>	A	Variable attenuator set to nominal attenuation. Measurement at an output power of 100W with a CW source.			22

## Solid State Broadband High Power Amplifier

**1191 – BBM5K8CKT**
**2500 – 6000 MHz / 100 Watts**

PA enable / Disable time	T <sub>ON/OFF</sub>	uSec	Variable attenuator set to nominal attenuation. Measurement with 0dBm CW signal presented to the input of the amplifier. Rise and fall times of amplifier output envelope recorded. Rise and fall times at 10% / 90% of the output power in linear scale. PA Enable / Disable signal set to 10kHz repetition rate and 50% duty cycle.			1
--------------------------	---------------------	------	---	--	--	---

### PA PROTECTION / RUGGEDNESS

The PA includes protection circuits for:

- Over temperature
- Over voltage
- Reverse polarity
- Over current

In addition to protection circuits, the PA will withstand full reflection at the RF output port at any angle for up to 1 minute at P3dB.

### ENVIRONMENTAL SPECIFICATIONS

Parameter	Symbol	Min	Typ	Max	Unit
Operating Case Temperature	T <sub>C</sub>	-40		+85	°C
Storage Temperature	T <sub>STG</sub>	-40		+85	°C
Relative Humidity (non-condensing)	RH			95	%
Altitude (MIL-STD-810F Method 500.4)	ALT			30,000	Feet
Vibration/Shock MIL-STD-810F Method 514.5/516.5 – Proc 1	VI/SH		Airborne		

### MECHANICAL SPECIFICATIONS

Parameter	Value	Units	Limits
Dimensions	8.0 x 6.5 x 1.0	Inch	Max
Weight	3.5	lb.	Max
RF Connectors	Input: Type-SMA, Female Output: Type-TNC, Female		
DC Interface Connector	Hybrid – D-Sub 17-Pin, Male (17W2)		
Cooling	External Heatsink Required (not supplied)		

# Solid State Broadband High Power Amplifier


1191 – BBM5K8CKT

2500 – 6000 MHz / 100 Watts

## DC INTERFACE CONNECTOR

Pin #	Description	Specifications
A1	GND	Ground Return
A2	VDD	Supply Voltage: +26.0 – 32.0V <sub>DC</sub> , 28.0V <sub>DC</sub> Nominal
1	RS485 (-)	Serial Communication Bus
2	Temperature Reporting	Analog Output Voltage @ 10 mV/°C with a 500 mV offset (i.e. 0.75V = 25°C)
3	Address 1	Hardware Address 1
4	Address 3	Hardware Address 3
5	Attenuator Setting	Voltage input in the range of 0.5 – 3.0V <sub>DC</sub> , 0.5V <sub>DC</sub> corresponds with minimum attenuation, 3.0V <sub>DC</sub> is maximum attenuation. Leave pin open or grounded to utilize RS-485 interface. (See RS-485 details below)
6	PA Enable	0/3.3V logic levels: Power Amplifier disable is a TTL Logic Low (0V). (Internally Pulled-High 3.3V) Leave pin open or pulled high to utilize RS-485 interface. (See RS-485 details below)
7	Alarm	Amplifier Alarm indicator: Normally TTL Low A logic High indicates a fault condition, 0/3.3V Logic Levels
8	RS485 (+)	Serial Communication Bus
9	Current Reporting	Analog output voltage range of 1V/10 A (i.e. 1.5V = 15A)
10	Address 0	Hardware Address 0 – Least significant bit
11	Address 2	Hardware Address 2
12	Address 4	Hardware Address 4 – Most significant bit
13	Not Used	No Connection
14	Not Used	No Connection
15	Reset	Hardware reset Logic 0 to reset PA and clear latched faults

## OUTLINE DRAWING



## Solid State Broadband High Power Amplifier

1191 – BBM5K8CKT

2500 – 6000 MHz / 100 Watts

### RS-485 User Interface


The following settings are used for serial communications:

- Baud rate: 115,200
- Start bits: 1
- Data bits: 8
- Stop bits: 1
- Parity: None
- Handshake: None

### Frame and Message Structures

#### ***Frame structure***

The serial link will be asynchronous, and follows a typical RS485 frame structure. The frame structure is defined in the figure below.




**Figure 1: Serial interface frame structure**

Each frame is 10 bits in length and will begin with a start bit, followed by 8 data bits and finally a single stop bit.

#### ***Message structure***

A message is comprised of at least 6 frames. The figure below provides the message structure.



**Figure 2: Serial interface message structure**

## Solid State Broadband High Power Amplifier

1191 – BBM5K8CKT

2500 – 6000 MHz / 100 Watts

### **Master Address**

A7 A6 A5 A4 A3 A2 A1 A0  
 X X X X X X X X

Master Address is not evaluated

### **Slave Address**

A7 A6 A5 A4 A3 A2 A1 A0  
 0 0 0 16 8 4 2 1

32 Slave addresses are possible (If no address lines are strapped on hardware, unit defaults to address 0)

### **Len**

Len contains the number of bytes that follow, from Status to Checksum.

### **Status**

Master should load this with zero.

Slave will echo back status of the command after it is evaluated.

Possible Slave responses:

Value	Description
0x00h	Message received and decoded successfully
0x13h	Checksum error
0x2Bh	Command not available

**There are 7 supported RS-485 commands, detailed below.**

## Solid State Broadband High Power Amplifier

1191 – BBM5K8CKT

2500 – 6000 MHz / 100 Watts

### ***Null***

The null command responds with message status. It is used for a basic test of the communications link.

Command frame value (hex)	0x00
Length frame value (hex)	0x03
Command data	none
Slave response	Echo with status set

Example:

```
[8/30 17:58:15.3]SEND: 00 00 03 00 00 03   .....
[8/30 17:58:15.4]RCV: 00 00 03 00 00 03   .....
```

### ***Soft reset***

Performs a restart of the system.

Command frame value (hex)	0x04
Length frame value (hex)	0x03
Command data	None
Slave response	Echo with status set

Example:

```
[8/30 18:09:39.0]SEND: 00 00 03 00 04 07   .....
[8/30 18:09:39.1]RCV: 00 00 03 00 00 03   .....
```

### ***Set power up condition***

Sets the state of the amplifier bias on application of DC or reset.

Command frame value (hex)	0x05
Length frame value (hex)	0x03
Command data	2 bytes: 0x0001 sets power up condition to bias enabled. 0x0000 sets power up condition to bias disabled.
Slave response	Echo with status set

## Solid State Broadband High Power Amplifier

1191 – BBM5K8CKT

2500 – 6000 MHz / 100 Watts

### Example:

```
[8/30 18:13:08.5]SEND: 00 00 05 00 05 00 01 01 .....
[8/30 18:13:12.3]RCV: 00 00 03 00 05 06      .....
```

### ***Disable***

Disables amplifier bias.

Command frame value (hex)	0x06
Length frame value (hex)	0x03
Command data	None
Slave response	Echo with status set

### Example:

```
[8/30 18:14:36.7]SEND: 00 00 03 00 06 05 .....
[8/30 18:14:36.8]RCV: 00 00 03 00 06 05      .....
```

### ***Enable***

Enables amplifier bias.

Command frame value (hex)	0x07
Length frame value (hex)	0x03
Command data	None
Slave response	Echo with status set

### Example:

```
[8/30 18:15:35.4]SEND: 00 00 03 00 07 04 .....
[8/30 18:15:35.5]RCV: 00 00 03 00 07 04      .....
```

### ***Set input attenuation***

Sets the attenuation level.

#### Notes:

- The RS-485 attenuation value overrides voltage control on pin 5.
- The value of the attenuation can only be increased from the factory value.
- The gain of the amplifier is also a function of temperature compensation.
- Variations in gain versus temperature are expected, independent of the user attenuation setting.

## Solid State Broadband High Power Amplifier

1191 – BBM5K8CKT

2500 – 6000 MHz / 100 Watts

Command frame value (hex)	0x11
Length frame value (hex)	0x05
Command data	<p>2 bytes. The first byte is 0 and the second byte is the mixed number attenuation value.</p> <p style="text-align: center;"> <math>\frac{D7 \ D6 \ D5 \ D4 \ D3 \ D2 \ D1 \ D0}{0 \ 0 \ 16 \ 8 \ 4 \ 2 \ 1 \ .1/2}</math> </p> <p>Examples:            30dB is 0x00 0x3C            8.5dB is 0x00 0x11</p>
Slave response	Echo with status set

Example for setting 8.5dB user attenuation:

```
[9/4 15:45:49.9]SEND: 00 00 05 00 11 08 05 19 .....
[9/4 15:45:49.9]RCV: 00 00 03 00 11 12 .....
```

### Get status

Returns current status of amplifier

Command frame value (hex)	0x02
Length frame value (hex)	0x03
Command data	None
Slave response	<p>Input Current (2 bytes)</p> <p>Input Voltage (2 bytes)</p> <p>Temperature (2 bytes)</p> <p>Attenuator Setting (2 bytes)</p> <p>Alarm Register (2 bytes)</p>

Example:

```
[8/30 17:59:39.5]SEND: 00 00 03 00 02 01 .....
[8/30 17:59:39.5]RCV: 00 00 0D 00 02 00 0A 0A .....
0008: C4 00 19 00 11 00 00 C3 ...
```




## Solid State Broadband High Power Amplifier

1191 – BBM5K8CKT

2500 – 6000 MHz / 100 Watts

Voltage	16 bit signed, 1/100 <sup>th</sup> of a Volt	+327.67 / - 327.66 V
Current	16 bit unsigned in 1/100 <sup>th</sup> of an Amp	0 ~ 65535 in hundredths of an Amp
Temperature	16 bit signed in whole degrees	+32767 / -32766 degrees Centigrade

### ALARM REGISTER



### Notes on Alarms

- Any alarm condition will pull the Alarm line high (Pin 7)
- For Latched Current Alarm, the input power is attenuated by approximately 15 dB.
- For Latched Voltage or Temperature, the unit will disable.
- A Software or Hardware reset is required to clear Latched Alarm.